

UPR Legacy Equipment Cross Reference Table:

Legacy Dynisco 1/4 Din Indicator Model	Current Dynisco 1/4 Din Indicator Model	Alarm Relay Code	Secondary Input	MOD bus Comms	24V Transmitter Power	2nd Retransmission	USB Only	Data Logger with USB	Power Supply Option
UPR800/700-0-0-3-A3	UPR900	3	0	0	0	0	0	0	0
UPR800/700-0-0-5-A3	UPR900	3	0	0	0	0	0	0	1
UPR800/700-0-2-3-A3	UPR900	4	0	0	1	1	0	0	0
UPR800/700-0-2-5-A3	UPR900	4	0	0	1	1	0	0	1
UPR800/700-1-0-3-A3	UPR900	3	1	0	0	0	0	0	0
UPR800/700-1-2-3-A3	UPR900	4	1	0	1	0	0	0	0
UPR800/700-1-3-3-A3	UPR900	4	1	1	1	0	0	0	0
UPR800/700-0-0-3	UPR900	2	0	0	0	0	0	0	0
UPR800/700-0-0-5	UPR900	2	0	0	0	0	0	0	1
UPR800/700-0-2-3	UPR900	2	0	0	1	1	0	0	0
UPR800/700-0-2-5	UPR900	2	0	0	1	1	0	0	1
UPR800/700-0-3-3	UPR900	2	0	1	1	1	0	0	0
UPR800/700-0-3-5	UPR900	2	0	1	1	1	0	0	1
UPR800/700-1-0-3	UPR900	2	1	0	0	0	0	0	0
UPR800/700-1-0-5	UPR900	2	1	0	0	0	0	0	1
UPR800/700-1-2-3	UPR900	2	1	0	1	0	0	0	0
UPR800/700-1-2-5	UPR900	2	1	0	1	0	0	0	1
UPR800/700-1-3-3	UPR900	2	1	1	1	0	0	0	0
UPR800/700-1-3-5	UPR900	2	1	1	1	0	0	0	1

Dynisco strongly recommends that the end user consult the product specification sheets for both the older and newer replacement instrument, prior to purchase.

These specification sheets can be found on our website:

<https://www.dynisco.com/sensors-and-measurement/instruments>

<https://www.dynisco.com/sensors-and-measurement/legacy-instrumentation-products>